Computer Networking Lab

Assignment No 02

Date: 11/01/2023

Name: Harshavardhan Anil Bamane

PRN: 22510112

Networking Commands

Windows Commands:

1. ipconfig:

- Function: Displays the IP configuration for all network interfaces on a Windows machine, including IP address, subnet mask, and default gateway.

2. ping:

- Function: Sends ICMP Echo Request messages to a specified network host to check network connectivity.

```
C:\Users\harsh>ping 8.8.8.8

Pinging 8.8.8.8 with 32 bytes of data:

Reply from 8.8.8.8: bytes=32 time=8ms TTL=113

Reply from 8.8.8.8: bytes=32 time=65ms TTL=113

Reply from 8.8.8.8: bytes=32 time=65ms TTL=113

Reply from 8.8.8.8: bytes=32 time=8ms TTL=113

Ping statistics for 8.8.8.8:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

Approximate round trip times in milli-seconds:

Minimum = 8ms, Maximum = 65ms, Average = 22ms
```

3. tracert:

- Function: Traces the route that packets take to reach a destination, showing the IP addresses of the routers along the way.

tracert < hostname or IP address>

```
Tracing route to dns.google [8.8.8.8]

over a maximum of 30 hops:

1  1 ms  1 ms  4 ms  10.40.0.2

2  21 ms  1 ms  1 ms  172.16.16.1

3  2 ms  1 ms  1 ms  112.133.247.221
```

4. nslookup:

- Function: Performs DNS (Domain Name System) queries to retrieve information about domain names, IP addresses, and mail servers.

nslookup <hostname>

```
C:\Users\harsh>nslookup
Default Server: one.one.one.one
Address: 1.1.1.1
```

5. netstat:

- Function: Displays active network connections, listening ports, and other network-related information.

netstat -a

```
∷\Users\harsh>netstat
Active Connections
 Proto Local Address
                               Foreign Address
                                                      State
        10.40.5.223:49675
                               1.2.3.4:9922
                                                      ESTABLISHED
        10.40.5.223:49701
                               20.212.88.117:https
                                                      ESTABLISHED
 TCP
        10.40.5.223:49965
                               sh-in-f188:5228
                                                      ESTABLISHED
        10.40.5.223:49980
                               52.111.244.0:https
                                                      ESTABLISHED
 TCP
                               sc-in-f188:5228
 TCP
        10.40.5.223:50101
                                                      ESTABLISHED
 TCP
        10.40.5.223:50178
                                                      ESTABLISHED
                               1:https
                               20.198.119.143:https
 TCP
        10.40.5.223:50206
                                                      ESTABLISHED
        10.40.5.223:50282
                               52.108.9.12:https
                                                      ESTABLISHED
```

6. arp:

- Function:Displays and modifies the ARP (Address Resolution Protocol) cache, showing the mapping between IP addresses and MAC addresses.

arp -a

```
C:\Users\harsh>arp -a
Interface: 10.40.5.223 --- 0x8
 Internet Address
                       Physical Address
                                              Type
                       00-04-96-a1-fb-0b
                                              dynamic
 10.40.0.2
 10.40.6.25
                                              dynamic
                        3c-55-76-a8-01-c3
 10.40.9.189
                       b8-bc-5b-df-1b-b8
                                              dynamic
 10.40.9.200
                       b8-bc-5b-df-19-ec
                                              dynamic
 224.0.0.2
                       01-00-5e-00-00-02
                                              static
 224.0.0.22
                       01-00-5e-00-00-16
                                              static
                       01-00-5e-00-00-fb
 224.0.0.251
                                              static
                       01-00-5e-00-00-fc
 224.0.0.252
                                              static
                       01-00-5e-7f-ff-fa
 239.255.255.250
                                              static
 255.255.255.255
                        ff-ff-ff-ff-ff
                                              static
```

7. route:

- Function: Displays and modifies the local IP routing table, showing the routing information for network destinations.

route

```
C:\Users\harsh>route
Manipulates network routing tables.
ROUTE [-f] [-p] [-4|-6] command [destination]
                 [MASK netmask] [gateway] [METRIC metric] [IF interface]
              Clears the routing tables of all gateway entries. If this is
  -f
              used in conjunction with one of the commands, the tables are
              cleared prior to running the command.
              When used with the ADD command, makes a route persistent across
  -p
              boots of the system. By default, routes are not preserved
              when the system is restarted. Ignored for all other commands,
              which always affect the appropriate persistent routes.
              Force using IPv4.
  -4
              Force using IPv6.
  -6
              One of these:
  command
                           Prints a route
                PRINT
                ADD
                           Adds
                                  a route
                           Deletes a route
                DELETE
                          Modifies an existing route
                CHANGE
```

8. nbtstat:

- Function: Displays NetBIOS (Network Basic Input/Output System) over TCP/IP statistics, including NetBIOS name resolution.

nbtstat -a <hostname or IP address>

```
C:\Users\harsh>nbtstat
Displays protocol statistics and current TCP/IP connections using NBT
(NetBIOS over TCP/IP).
NBTSTAT [ [-a RemoteName] [-A IP address] [-c] [-n]
       [-r] [-R] [-RR] [-s] [interval] ]
      (adapter status) Lists the remote machine's name table given its name
 -a
      (Adapter status) Lists the remote machine's name table given its
                       IP address.
                       Lists NBT's cache of remote [machine] names and their IP addresses
      (cache)
       (names)
                       Lists local NetBIOS names.
                       Lists names resolved by broadcast and via WINS
       (resolved)
                       Purges and reloads the remote cache name table
       (Reload)
      (Sessions)
                       Lists sessions table with the destination IP addresses
      (sessions)
                       Lists sessions table converting destination IP
                       addresses to computer NETBIOS names.
 -RR (ReleaseRefresh) Sends Name Release packets to WINS and then, starts Refresh
 RemoteName
              Remote host machine name.
 IP address
              Dotted decimal representation of the IP address.
 interval
              Redisplays selected statistics, pausing interval seconds
              between each display. Press Ctrl+C to stop redisplaying
              statistics.
```

9. ipconfig /all:

- Function:Provides a detailed view of the IP configuration for all network interfaces, including additional information such as DHCP lease details and DNS server addresses.

ipconfig /all

```
:\Users\harsh> ipconfig /all
Windows IP Configuration
  Host Name . .
                 . . . . . . . . . MiksuHarsh17
  Primary Dns Suffix ....:
  Node Type . . . . . . . . . : Hybrid
  IP Routing Enabled. . . . . . : No
  WINS Proxy Enabled. . . . . . : No
Ethernet adapter Ethernet:
  Media State . .
                             . . : Media disconnected
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Killer E2600 Gigabit Ethernet Controller
  Physical Address. . . . . . . : 08-8F-C3-5D-EB-F7
  DHCP Enabled. . . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 1:
  Physical Address. . . . . . . : B0-3C-DC-E9-59-B8
  DHCP Enabled. . . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
  Description . . . . . . . . : Microsoft Wi-Fi Direct Virtual Adapter #2
  Physical Address. . . . . . . : B2-3C-DC-E9-59-B7
  DHCP Enabled. . . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter WiFi:
  Connection-specific DNS Suffix .:
  Description . . . . . . . . . . Killer(R) Wi-Fi 6 AX1650i 160MHz Wireless Network Adapter (201NGW)
  Physical Address. . . . . . . : B0-3C-DC-E9-59-B7
  DHCP Enabled. . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
```

10. netsh:

- Function: A versatile command-line tool for configuring and troubleshooting network settings. It allows you to manage various network aspects, including interfaces, firewalls, and routing.

netsh interface show interface

11. pathping:

- Function: Combines the functionality of tracert and ping, providing a detailed analysis of the network path and packet loss between the source and destination.

pathping <hostname or IP address>

Linux Commands:

1. ifconfig:

- Function: Displays information about network interfaces, including IP address, MAC address, and network-related statistics.

ifconfig

2. ping:

- Function: Sends ICMP Echo Request messages to a specified network host for testing network connectivity.

ping <hostname or IP address>

```
→ ~ ping 8.8.8.8
ping: connect: Network is unreachable
→ ~ ping 8.8.8.8
PING 8.8.8.8 (8.8.8.8) 56(84) bytes of data.
64 bytes from 8.8.8.8: icmp_seq=1 ttl=57 time=68.9 ms
64 bytes from 8.8.8.8: icmp_seq=2 ttl=57 time=44.0 ms
64 bytes from 8.8.8.8: icmp_seq=3 ttl=57 time=37.3 ms
64 bytes from 8.8.8.8: icmp_seq=4 ttl=57 time=35.5 ms
```

3. traceroute:

- Function: Traces the route taken by packets to reach a destination, displaying the IP addresses of routers along the path.

traceroute < hostname or IP address>

4. dig:

- Function: A flexible tool for querying DNS servers, providing detailed information about domain names and DNS records.

dig <hostname>

```
| Some Delie | Company | C
```

5. netcap:

-Function: Displays information about active network connections, listening ports, and routing tables.

6.arping:

-Function: Displays and manipulates the ARP cache, showing the mapping between IP addresses and MAC addresses.

```
The Execute

The Action of Parts Company

Th
```

7. routel:

- Function: Displays and modifies the IP routing table, showing the routing information for network destinations.

routel

8. nslookup:

- Function: A tool for querying DNS to obtain information about domain names and IP addresses.

nslookup <hostname>

9. iwconfig:

- Function: Displays information about wireless network interfaces, including details about the connection status, signal strength, and encryption.


iwconfig

```
Type-Encode

Type
```

10. ss:

- Function: A replacement for netstat, ss provides detailed information about socket statistics, including listening ports, established connections, and more.



12. iptables:

- Function: A powerful tool for configuring and managing firewall rules on Linux systems. It allows you to define rules for packet filtering and network address translation (NAT).

iptables -L

These commands are fundamental for **network troubleshooting**, **diagnostics**, and **configuration** in both Windows and Linux environments.